

# Belt conveyor with stand

BF40 - EIK - W250 - L5000 - 5 - RH2 - V - 0 - Kn8 - SL10 - SR10 - A200 - B300 - D500 - E500 - 1 - 14 - Z

**Size**  
BF40  
BF80

**Type**  
E = End drive  
M = Mid drive

**Knife edge**  
IK = In Feed  
OK = Out Feed  
DK = Double / Both  
Leave blank = None

**Width (W)**  
(mm)

**Length (L)**  
(mm)

**Speed**  
4, 5, 6, 8, 9, 12, 19, 25, 37 (m/min at 50 Hz)  
0 = No drive unit included

**Drive position**  
R = Right  
L = Left

**Drive orientation**  
H1, H2, H3, H4, V1, V2, V3, V4  
Leave blank = No drive unit

**Belt type**  
See website or contact us for further information.

**Belt profiles**  
0 = No  
1 = Yes

**Tracking guides**  
Kn6 (6x4x4)  
Kn8 (8x5x5)  
Kn10 (10x6x6)  
2xKn6  
2xKn8  
2xKn10  
Leave blank = None

**Conveyor guides left (SL)**  
10-100 (mm)  
0 = None

**Conveyor guides right (SR)**  
10-100 (mm)  
0 = None

**First leg distance (A)\***  
(mm)  
0 = Without stand

**Last leg distance (B)\***  
(mm)  
0 = Without stand

**Start height (D)\***  
(mm)  
0 = Without stand

**End height (E)\***  
(mm)  
0 = Without stand

**Stand attachment type\***  
0 = Without stand  
1 = Corner Brackets  
2 = T-Plate

**Feet type\***  
00 = None  
01 = Swivel castor with total lock and bolt hole  
03 = L-Based Foot  
04 = Angle Foot AI, adjustable  
14 = Knuckle Foot

**Customized**  
Z = Yes

**\*Note:**

A, B, D, E, stand attachment and feet will all have the value 0 if the conveyor is defined without a stand. It is possible to have a stand without feet (00) but a stand attachment must be selected.