

Belt Conveyor

Size

BF40

BF80

Type

E = End

M = Middle

Knife edge

IK = In Feed

OK = Out Feed

DK = Double / Both

Width

Length

c/c roller

Speed

Motor side

R = Right

L = Left

Motor orientation

H1

H2

H3

H4

V1

V2

V3

V4

Belt type

See website or contact us for further information.

Conveyor guides left

0 = No guides

1 = Bent side

2 = Side support alu

3 = Adj. side support

Conveyor guides right

0 = No guides

1 = Bent side

2 = Side support alu

3 = Adj. side support

Belt profiles

0 = No option

1 = Quadratic profiles

2 = Thin profiles

3 = Wide angled profiles

4 = Side walls

Tracking guides

0 = None

1 = K6 (6x4x4)

2 = Kn8 (8x5x5)

3 = Kn10 (10x6x6)

BF40E IK - 1200 - 1000 - 38 - RV4 T L F 5 B - 1 1 0 0 0 0

Stand

- 0 = No
- 1 = Yes

Motor

BF40:

- 0 = No motor
- 1 = MS63A-4
- 2 = MS63B-4
- 3 = MS63C-4
- 4 = ML63B-4

BF80:

- 0 = No motor
- 5 = MS71A-4
- 6 = MS71B-4
- 7 = MS80A-4
- 8 = MS63B-4 B5

Stand

BS

40

-

XXXX

-

XXXX

HXXX

-

X

-

XXXX

0

0

02

Profiles

40 = 40x40 Semi Profiles

80 = 40x80 Semi Profiles

Width

Length

Height

No. of sections

Profile length (l1)

Attachments

1 = Corner Brackets

2 = T-Plate

Foot plate

0 = Without foot plate

1 = Without foot plate

Floor attachments

01 = Swivel castor with total lock and bolt hole

02 = Swivel castor with bolt hole

03 = L-Based Foot

04 = Angle Foot AI, adjustable

05 = Adjustable Foot Ø 39 M8 / L 65

06 = Adjustable Foot Ø 39 M10 / L 65

07 = Adjustable Foot Ø 79 M8 PSD / L 71

08 = Adjustable Foot Ø 79 M10 PSD / L 71

09 = Adjustable Foot Ø 79 M12 PSD / L 71

10 = Adjustable Foot Ø 79 M16 SVD / L 161

11 = Adjustable Foot Ø 79 M10 SVDB / L 71

12 = Adjustable Foot Ø 79 M12 SVDB / L 151

13 = Adjustable Foot Ø 79 M16 SVDB / L 161

Note:
All our conveyors are skillfully adjusted and tested on our factory floor before delivery. After delivery and placement however we cannot guarantee perfect running and strongly recommend final adjustments to be made. Please see the documentation provided with the conveyor for more information on how best to do this. Note that most tracking problems occur from uneven assembly of conveyor bases or flooring and that belt tension should be maintained when adjustments made.
Motors are not individually tested and not assembled to the unit during transport.